

Installation Instruction

Rear Spoiler

Please check fitment of the trunk spoiler before painting! After painting please apply the partnumber sticker to the left side of the spoiler.



Before bonding the spoiler to the trunk, please make sure the trunk has been cleaned and has a grease free surface.

Please mark the position of the spoiler on the trunk with removable ink or a pencil before bonding!

Remove the protective film from the tape and press the spoiler firmly on the position you just marked.

Now mount the side brackets as shown in the pictures.

