



**I.L. MOTORSPORT**

# Installation instructions

Illuminated gear knob  
ND0-301620-301621

06.2024

Package	A: Gear knob	1 Piece
Contents:	B: Shift boot	1 Piece
	C: Sheathed cable	1 Piece
	D: Connector	2 Pieces
	E: Splice Connectors	2 Pieces
	F: Fuse 10A	1 Piece
	G: Fuse holder	1 Piece



## Attention important!

Before installing the new gear knob, make sure to secure the cables with adhesive tape as follows to prevent damage. (Picture 1 and 2)



Picture 1



Picture 2


1. Unscrew the gear shift knob (picture 3), then loosen the frame with shift boot by pulling the frame up all around until all retaining clips have loosened (picture 4) and take it out.(picture 5)



Picture 3



Picture 4



Picture 5

2. Dismantle the center console by loosening both screws (picture 6) and pulling the center console out of the retaining clips.(picture 7) Loosen the plug connection under the center console.(picture 8)



Picture 6



Picture 7



Picture 8

3. Replace the shift boot by loosening the two screws on the frame (Picture 9), separating the old shift boot from the frame and installing the new one in the reverse order. (Picture 10 and 11)



Picture 9



Picture 10




Picture 11



4. There are two different ways to illuminate the gear knob.

- a. Connection via the lighting cable. The knob only lights up when the lighting is switched on.
- b. Connection via the ignition plus wire. The knob lights up as soon as the ignition is switched on.

5. Lay the cable up to the shift lever. (Picture 12) Mount the center console and guide the cable through the opening in the shift boot. (Picture 13) Clip the frame with shift boot into the center console and screw the gear knob onto the shift lever. (Picture 14)



Picture 12



Picture 13



Picture 14

6. Connect the cables (picture 15) and pull the shift boot up into the groove of the gear knob (picture 16), which is now fixed there.



Picture 15



Picture 16